

# Actuated Valve Sensor

## Sensor Selector



| Germany



<u>Area</u>	<u>Sensor</u>	<u>Connector</u>	<u>Target Puck</u>	<u>For Actuator</u>
<b>Safe Zone (24VDC)</b>	IN5331 	EVC811 	E12517 	EBRO Actuator <b>(EB4/5/6/8/10/12/14/16/18/20/22)</b>
	IN5331 	EVC811 	E12517 + <b>E12526</b> 	HKC HP Actuator (HP50/63/66/75/88/100/115/125)
	IN5331 	EVC811 	E17328 	HKC HP Actuator (HP145/160/180/200/210/211/212)
<b>Explosion Proof Zone  (EXIA) Intrinsically Safe</b>	NN5013 	E1003A 	E12517 	EBRO Actuator <b>(EB4/5/6/8/10/12/14/16/18/20/22)</b>
	NN5013 	E1003A 	E12517 + <b>E12526</b> 	HKC HP Actuator (HP50/63/66/75/88/100/115/125)
	NN5013 	E1003A 	E17328 	HKC HP Actuator (HP145/160/180/200/210/211/212)